


asm1166 spi flash update SOP

Note: Program tool have to run it on real DOS environment, not Windows DOS mode

1. Please unzip RE116X.A10.zip and copy RE116X.A10 folder to C:\
2. Boot into DOS
3. Please into C:\RE116X.A10
4. Type " autoexec.bat " to start update firmware
5. When screen shown " PASS : 1 " & Finish ! that's mean update finish and successful.



Check new Firmware version

Firmware Version: 201105_00_00_00

